

TAP REAR EDGE

TAP FRONT EDGE

Pilot drill holes

48.5mm

Dispense Point
(Make sure within sink region)

Important: Before making any cuts or drilling into the work surface, ensure the area below is free from water pipes or electrical cables. There is risk of serious injury or death if electrical cables are cut, and significant damage to property if a water pipe is cut.

1. Decide where you want the Porpoise to be mounted, and mark the centre and the desired distance away from the work surface edge. Its important the dispense point is within the sink region. Secure the template in place with masking tape.
2. Drill the Porpose utilities hole (Centre) with a 30mm hole cutter. We recommend drilling a 4mm pilot hole first.
3. To fix the porpoise tap to the work surface, drill the three radial holes using a 7mm drill bit. we recommend drilling a 4mm pilot hole first.
5. Remove the template.
6. Remove the waste pieces of work surfaces.
7. Clean up any sawdust left behind, and make sure the surface is left clean and dry.